

Scrambler

Modernized with readily available part values,
pulldown resistors and true-bypass switching

Sw1 - Heavy Duty DPDT Footswitch

Transistors - Q1, Q3, Q4 - 2N5306
or other Darlington

Q2 - BC169B or
other NPN (2N3904, etc)

Diodes - 1N456
or 1N914

